CHAIN SAW PARTS LIST

XL-113 XL-114 XL-122*

HOMELITE

ALC: LA DE LA D

*INTERNATIONAL SALES ONLY Part No. 24360 Rev. 1




FIGURE 1

ALWAYS FURNISH MODEL AND SERIAL NUMBER WHEN ORDERING PARTS.

					÷	ť	닅		
		No.	Besoription	Part No.	붋		뒪	Qty.	
		Detr.	Description		x x				
OSER MENO	17205		SCREW-bex, 8-32 x1/2	60983	×	x	×	4	
US ER MEMO	//200	I	HOUSING-Ian	A-67192-8				1	
		2		67181				4	
		3	Includea: STUD-drive SCREEN-fan housing	65491				i	
		4		87222				1	
		5	RING-att flow					1	
		6	BUSHING-starter rope					i	
		7	ORIP-starting rope	64105				1	
		8	INSERT-rops retaining	84164					
		8	ROPE-starter	69669				1	
		10	WASHER	67165	x	х	ĸ	1	
		II	6HIELD-apping (masr)	69729	х	x	х	1	
		12	SPRING-rewind	83670	x	x	x	1	
		13	SHIELD-spring (outer)	63714	х	ж	х	1	
		14	RING-shield retaining	83675	x	х	х	1	
		15	LOCK-spring	64948	x	х	x	1	
		10	PULLEY & CUP ASSY.					I	
				84874				1	
		17	BUSHD43-starter post	63606				1	
		18	WASHER-retaining	80848				î	
		19	SCREW-bax, 10-92 x 1/2					i	
		20	NUT-lock, 5/16-24	81112					
		21	WASHER-flat, 6/16	64085-1				1	
		22	STUD-shoulder	62677				2	
		23	PAWL-starter	84442				2	
		24	WASHER-flat	63861	x	x	х	2	
		26	SPRING-starter pawl	56756-2	π.	ĸ	х	2	
		28	ROTOR - mumeto	83687	x		х	í	
		27	COL-(ga)too	84091	x		х	I	
		28	SCREW-coll opre	64021	ж		x	2	
		29	LEAD-ground to switch	A-68989	x		х	1	
		30	CORE-col	54422	x		x	1	
				A-83066		×		1	
		81	TERMINAL-spark plug	75078					
		22	KEY-woodrufi	84301		~		_	
		38	RETAINER-lead	-				-	
		34	CONDENSER & CLAMP	64086				-	
		35	SCREW-condenser damp	55411					
		36	BCREW-terminal	64090				-	
		37	BLOCK-terminal	640B8					
		38	SCREW-back plate retainer	66321					
		39	LEAD-high teorion	6 B966					
		€0	BEARING-roller	67385	x				
		41	SEAL	56868-A	X		ж		
		42	PLATE-back	63624-1A	x		x		
		43	CLIP-coil relaining	64423	Ä		×	1	
		44	SCREW-coll retaining cho	68872	π		х	1	
		45	SCREW-breaker clamp	76431	a		х	2	
		48	POINT-ast w/ielt	A-64067	π		х	1	
		49	Includor: WASHER-post	29026			x	-	
			CLIP-post	28008				_	
		48		64089					
		49	RETAINER-Seit	A-83928				-	
		50	COVER-breaker box					-	
		\$1	WASHER-flat, #8	84018					
		52	SCREW-GOVER	64086	х				
		88	ROTOR-magneto	67284				1	
		54	CAP-dust	64413				1	
		🕑 M	SCREW-pan, 8-32 x 🗰 🕉					2	
		Ø 56	WASHER-lock, #8	1000	vz	⊆ x		Б	
		67	MODULE-uppition	67283		х		1	
		58	SCREW-pan, 6-32 x 5/16	80605		х		1	
		69	CLAMP-condenser Isad	67285		X	:	1	
		60	PLATE-back	A-67287		x		1	
		61	Includes. SEAL	5 69 6 8- A		x		I	
		62	BEARINQ-TOILER	87395				1	
			CORE & COIL	87277				1	
		69		67483				ī	
		84	LEAD-trabajormer	87275				i	
		6 5	TRANSFORMER	80183		, ,		ż	
		68	SCREW-fil, 8-82 x 7/B			x		ĩ	
		67	LEAD-condenser	67280				1	
		68	CONDENSER	67281		a A			
		69	LBAD-bigh tension	67464		*		3	
		Ø 10	SCREW-pan, 8-32 x			,	6	2	
		-	¥8	82177					
			•						

ALWAYS FURNISH MODEL AND SERIAL NUMBER WHEN ORDERING PARTS.




FIGURE 2

	FIGURE												
No.	Description	Part No.	XI-113			Qty.	No.	Description	Part No.	NL-113	XI-1X	XL-125	QLY.
t	PISTON & PIN	A-07686	x	; ;	x	1	+ 14	ETOP-raci	87418-1			¥	1
8	Includes PLITON RING-"L"shaped	82340	x ;		×	1	36	6CREW-pan, 8-32 x 1/1	60675		×	-	2
3	AlbG-referring	75120	х 1	•	¥	1	36	SCREW-shoulder	64199-A	_	H		3
4	RING-picton pin retaining	64813	хı	•	x	1	*17	CAP-muifter	A-61827-1			I	1
6	ROD-manschitz	A-67411	х (•	х	1	3\$	SCR.BW-shoulder (See Note I)	64189-A	-	1	£.,	Ż
6	Includer, BEARINO-needle	67408	x a	6 3	π	1	89	CAP-nuffler (See Note 1)	64126		1	1	1
7	SCREW	80989	x ;	¢ (x	2	40	BAFFLE-mattler (Bes Note 1)	64123	¥		¥	1
8	GARGE T-OFRAKCARR	63.381-A	x)	: :	π	1	41	SCREW-box, 12-24 x 1/2 (See Note 1)	60821		1		3
8	KEY-weedruff	76078	ж.)	<pre></pre>	x	1	42	BODY-multier (See Note 1)	A-641J0	£	1	£	1
10	ROLLER-needle (set of \$1)	A-89437	x 2	•	x	1	4.k	EPARK PLUG	83047-9	¥	ĸ	ж	1
11	CRARESHAFT	63204-1	× J	•	π	1	46	Dichudos GASKET	2.603.8	-	H	x	1
13	SOREW-heating retainsy	59704	,,	•	t	2	4 G	CYLINDER	A-04043-2/	lπ			1
18	WARKER-scenal	63206	х)	¢ ;	x	2		CYLDDER	A-89129-1		ж		1
14	BEARING-ball	63866-8	х)	•	π	1		CYLINDER	64406-1			x	1
15	BIND-retaining	66018-A	хı	•	π	1	46	LINE-oil (masual)	4-87078	x	×	¥	1
16	DECAL	66146	х)	•	π	1	47	FITTING-sizesght	85896	×	x	¥	1
17	CAP-fuel filter	A-67901	x)	< ;;	x	1	48	CONNECTOR-slbow	31984	¥	×	¥	1
18	LINE-od (auto, upper)	8-61818	x >	•	z	1	49	NUT-hox, 1/4-38	SI080-2	Ŧ	x	ж	4
19	PUMP-automatic m	A-87023	x)	<pre></pre>	2	1	80	WAEHER-lock, 1/4	63008	¥	х	ж	4
±0	Includes, SCRXW-cam	64102-A	X J		I	1	51	PIN-compression relaise	А-67482		π		1
21	GAEKET	68736	. н	•	x	1	52	GANKET-cylinder	0.5629	х	Ā	x	1
32	SCREW-pan, 4-40 x 1/4	80918	x ı	6 8	π	2	58	STUD cylinder (loog)		ж		×	I
23	SEAL-felt	64393	× J	•	π	1	54	FIVOT FIN & BRACKET ASSY	A-64688-2				3
24	6CR EW-pen, 8-32 x 7/8	80556	κ,	•	π	de 👘	55	SCREW-µm, 6-32 x 3/8	806 11	н	x		1
25	WORM-oil pump	63229	хJ	: :	π	1		BCREW-pun, 6-32 x 3/8	80593			×	2
26	LINE-oil (auto, lower)	A-6J967	x ;	6 3	x	1	56	SPRING-relief Valvo	64653	ж	ĸ		3
E7	"O" <u>REM</u>	69074	ж	•	r	1	57	CLAMP-oil	65949-8		x	×	C
88	SBAL	68308-A	Ξ,	•	r	1	58	CLAMP-lever	84655-2		x		1
89	STUD-cylinder (short)	55871	X I	¢ 3	I	3	88	LEYER-roliot valvo	84664 13	x	×		1
	MUFFLER-read (complete)	A-87869-A	x i	•	¥	1	60	FLTER-01	A-64741	π	ж	x	1
4 30	Includes BDDY-mulfiler	A-67446-1A	i ar u	•	х	1	61	YALYB-chork	A-65848	π	х	x	I
31	SCREW-bex, 12-24 x 1/2	60821	ж	6 3	x	3	82	NDT-Dexlook, 6-32	01120	х	×		4
+92	BAFFLE-muffler	82460	* :	٤.	x	1		NUT-fimilock, 6-d2	01126			×	2
#38	RB2D- muffler	87394	x :	٤ :	z	1							

Denotes new parties

/ Optional

Note 1 - Used on International Units Only





FIGURE 3

49	•	63	
Ξ.	F.	a	
ι.	ι	ι,	
÷	ы	ы.	<u>.</u>

			XL-113						Paral bio	201-113		17	Q1y,
No.	Description	Part No.	и	* ;	4	Ctu.	ND.	Description	Part No.	~	~	~	41124
í	RETAINER-reed valve	84208		x		3	34	HANDLE- Brottle	A-07097-A			×	í 1
모	RBED-Valva	59678-B	x	x	x	4		HANDLE- Grouns	A-67608-A		ĸ		1
3	BEAT-read valve	64242	х	x	I	l		Includes RIVET-according [not shown]	05869	X		x	1
4	GASKET-rest valve seat	64288		x		1	35	GAEKS T-oil Lunk	67265		×		1
46	MANIFOLD-16take	A-87602-A	х	x	π	1	36	COVER-col Look	071J8-3		×		1
ð	<u>heludes</u> BOREW-pan, 8-32 x 1 1/4	89174	x	x	x	2	37	SCR 2W-51, 8-32 x I 5/8	82153		۲		1
7	BCR 8W-pap, 8-32 x 1	82179	ж	I	π	J	38	BCREW-01, 8-32 x 3/4	82106 64862		×		
8	SCREW-hox, 10-32 x 1 7/8	82173	x	×	x	8	38	GROMMET			*		î
9	GASKET-certurstor	67631	х	x	x	1	40	SCREW-Idle adjustment	G6022		ч		-
10	CARBURETOR	A-676B1	×	x	x	1	41	BUTTOR-choke	67289-3		۲		
11	NUT-DOVET TOURDE	A-87827	ĸ	x	х	1	42	SWITCH	A-03958				2
12	COVER-sur filter	62189-2	×	x	x	1	45	Includes. NUT	92084 - AJ		ж		1
18	RDQ-relating	58319 -A	x	¥	¥	1	44	PLATE-"On-On"	63910		×		1
14	FILTER ELEMENT-ar	A-63955-A	x	×	x	1	45	CAP-oil (vented)	A-652\$4		У		1
10	SCREW-bex, 12-24 x 1/2	80621	×	ж	*	1	46	Includes, "O" RING	65133		×		1
19	BRACKET-AIT filter COYEF	A-83576	x	×	¥	1		ATAR-Ashr (vor spowe)	G 3718		۹		1
19	PIN-cotte	86 324	π	х	¥	1	47	FIL FRR- 01 (manual)	A-64283		ж		1
18	WASHER-look, 410	83048	π	ж	х	2	48	LINE-flexible oil	64366		۲		1
19	RDD-chake	A-03942-I	×	x	x	1	6 9	QABK ZT	6973G		ж		1
20	ROD-throttle	63696-1	π	х	x	1	50	FITTING-phock valves	A-68936		x		!
*#1	BOOT-thrattle rod	87684	x	ж	ж	1	61	SCREW-set	69113		x		1
22	PIR-cotter	B6901	x	x	x	í	58	LEAD-ground	A-63939	۲		х	1
23	WAEHER-talt	63280		ж		I	68	GROMMET-"Hi-Lo"	58858		x		
24	COVER-throttle bandle	63589-5	к	х	×	1	5 1	SPRING-plunger	86080		х		
25	BUSKING-throttle look	64646	ж	×		I	56	PLUNCER-out pump	63061		X		
26	SPRING-throttle look	64877	x	ĸ		I	66	R DD-pluxger	A-65199		I		
27	PIN-throttle look	86592	x	x		3	57	Includes, "O" RING	56408		x		
2.8	BCR BW-pap, 8-32 x 1/2	80.680	x	*	*	2	5C	"O" RING	69074		N		
29	PIN-chrottle look	56984-1			x	3	58	NUT-plunger	65089	×	х		
30	SPRING-through Look	584D6			×	1	60	DUTTOR to Jump	67886	ж	×		
31	BUSHING-throttle Look	80064			x	i	61	SCR EW-hex, 18-84 x 5/8	60678		×		
38	RDO-refuming	88608			x	1	62	VENT-fuel (ank	A+65608			۲	
35	TRIGGER-through	64212-A	ж	I		i	63	GASKET throtile handle	8-528 7	٦	×	x	5

* Denotes now parts



EH XL 113 1 3411704

FIGURE 4

	No.	Description	Pare No.	XL-113		21-12	Հի յ,		h-0.	Description Parl No.	ZL-113		N 12	Qby.
ത	1	CAP-fuel filler 65253A	A-67301	x.	×	x	t			SPROCKET & DRUM-boe Note 1 A-64908	4	<i>e</i> 4	¥	1
	ż	Inclusion Lusskot	66937	x	×	x	1			BITH DOKET-J/6" pitch, 7 tooth OM68210	X	s x	Ā	1
	ī	LANG- fuel	03246		×	۹	1		33			к	π	1
	÷.	WASHEL	64182	•	×	\$	1		34	RACE-space 65998	¥	, N	π	1
	2	PILILR-inel	4-63420	х	×	×	1		88	WASHER-(brust (maar) 68893-1	9			1
	6	Includes FLL II R-felt	64083	х	۳	۴	1		36	BUMPER-spiked A-84722	- 1	97		1
	7	RANDLE DAN	4-65037-1	ж	×	x.	1		47	Includes Borow-bux, 13-24 x 4/8 50876	- 1	9	, f	2
	в	SCREW-501, 10-32 3 1	82120	ж	×	x	1		45	WASILER-lock #78 83000	- 6	i ∦	1	I
	9	BRACKE I-backlo ber	4-68666-t	۹	х	x	1	_	99	NU C-hux, 32-24 81008	1	1	+	2
	10	PAD-bi ackol	64610	H	×	×	1	Ð	₩₽	CRANKCASE & TANK \$68038 - OFFIT	, ,	x	X	1
	11	PLA FE-handle bar bracket	63586	x	×	x	1	+		Intiudes PIN-dowel [not shown] 71440	×	к и		2
	12	BC333 W-shouldes	64614-A	5	×	x	2			P1N-dowel (ոսն եննատ) 85868			x	
	14	GROMME 1-burkle has	64474	ж	х	x	2			83.41.(See Pag. 2, Index #28) 08308-A			π	1
	14	PLA FE-h undle iuu	65670	ж	х	x	1	ø	41	DAEKEL-Juch Lank 55304 - A			π	1
	13	PhD-bundle lat	66659	ж	۹	τ	1	- 0	42	COVER-fuel Lank A69040 A-65575-	A s	N 1	π	1
	16	GROLLA F-huxile bu	67056	۹	ж	π	1	-		Includes (not shown)				
	17	SCREW- հնյանվա	61754	×	x	×	1			GANKET-check valve 583.08			I	
- Ø	18	PLAIE-guide bis (inner) 67300	6351H-D	N	ж	¥	1			CAP-check ValVe 08839			λ	
	19	PEA Fb-guide bir (auter) 67297	63638-A	×	4	×	1		4 J	INEER P-taplock 92489			I	3
÷	30	PIN-bar adjusting	65768-1	h	٨	r	1		44	63868 (June (June)	3	к и		1
	21	N1/L-Io.k, 10-12	01211	5	۲	7	ĩ		45	STUD-13 inder (shari) 55871	×	< ×		
	42	WASHER-R11, 5/16	64032	×	5	х			44	SCHEW-fil, 8=d2 x 15/16 82353	×	(К		_
	63	NLT-hes, 5/16-18	81196	Ā	٦	۲	2		41	SCREW-51, 8-32 x 1 7/8 62154	۲		λ	
	24	ACALX-guide but adjusting	66944	π	۲	۲	1		48	BCR 258-51, 8-32 x 2 1/10 82355			X	
	23	COVLN-di sverdbo	A-64620-1	ъ	r	×	ב	-	49	BCREW-DL, 8-32 x 1 1/4 82153		(X		1
	26	Includes RIVE (~09 d head	86061	×	x	×	1	Ø		STUD-mude bar 67/93 - 03601	-	L X		2
	27	S)[[]_L[D=>,,wdust	64618	ж	۲	λ	3		\$1	DAER J-threaded 30896-A			×	
	28	PLA LL-cluich	6-1904-0		٦		1		52	INSER J-Luplack 79488		K X		
	29	PRDKClub	65842		х		ال ال		ارت	bCREW-hm, 12-24 x 2/8 80881	_			
	30	SHOB-clutch	69680-3		х		i.		•	K11-handje bar stop A-67700		K 3		
	31	CC/V22E-clutch	63671	ж	¥	x	1		54	inclusion SCRBW-pup, 10-39 x 5/8 80593		•	-	
	36	DRLM & HB	A-65888	ж	Ň	π	1		53	#1.012-handlo bar 67606-2)	< ×		1
										NO TE 3 - Data using A-54808 must use 53800 Throwt				

Opposition new parties

Optional

NOLE 1 Washer, 6 1890 limer Raco, 04323 Needla Bestring.

SPECIAL TOOLS (available on order)


A-23937-B	WRENCH-combination
22820-5	COLLAR-bearing installation (hearing to shaft)
22828	PLIERS-retaining ring
23186-1	SLEEVE-bearing and shaft installation
23528	WRENCH-socket screw (connecting rod)
23756	PLUG-needle bearing (connecting rod)
23759	SLEEVE-seal protection (back plate)
23846-2	ANVIL-roller bearing disassembly
A-23934	SPANNER-clutch
A-23949	TOOL-piston pin removal
A-23960	BRACKET-rotor removal
23972	SLEEVE-seel installation
24006-2	PLATE-shaft alignment
A-24051	JACKSCREW (bearing to shaft to crankcase)
24054	PLUG-seal assembly (crankcase)
24055	PLUG-bearing and seal assembly (back plate)
A-24057	BEARING REMOVER-(back plate)
24076	SLEEVE-seal protecting (crankcase side)
A-24138	REAMER-compression release
24230	DRIVER-hand, pozidriv
24173	DRIVER-check valve installation
A-23641-A	WRENCH-insert
24304	BIT-pozidriv #2
21001	DIT-DOMMIN IN

	Accessories
*A- 68074	SPARK ARRESTER-(Reed Muffler)
65548-1	HEAT EXCHANGER
A-64818	SPARK ARRESTER-Note 1

	Paint
24101	SPRAY CAN-dark blue
23475	SPRAY CAN-red

*Denotes new parts

NOTE 1-Used on International Units only



No,	Description	Part No.	Qty.	Na.	Description	Part No.	କ୍ଷ୍ୟୁ,
I	THROTTLE CHAFT ASSEMBLY	64225	1	19	COVER-fuel pump	870D2	1
2	SPRING-throttle return	/64230	1	20	SCREW-fuel pump cover	64694	4
3	SCREW ASSEMBLY	64689	7	*21	VALVE-throttle	677D0	1
4	DOVER-accelerator	67187	1	22	PLUG-limiting	64692	1
5	DIAPHRAGM-accelerator pump	/6718 8	1	23	COVER	64224	1
6	SPRING-accelerator pamp	/6424 0	I	24	METERING DIA PHRAGM ASSEMBLY	/642 86	1
7	NEEDLE-idle	/64241	1	25	GABKET-metering disphragm	64281	1
8	NEEDLE-high speed	/64242	1	26	VALVE-infet needle	64229	í
9	SPRING-needle adjusting	/642 86	2	27	SCREW-metering lever pin	464668	1
10	SPBING-choke friction	/64238	1	28	LEVER-metering	64246	1
11	BALL-choke friction	/60051	1	29	PIN-metaring lever	434244	1
12	VALVE-ohoke	64228	1	80	SFRING-metering lever	434237	1
13	SCREW-valve	/6469 3	2	81	FLUG-welch (main)	/664B2	1
14	JET-idle air	64690	1	32	FLUG-walch (idle)	/ ∂0818	1
15	CHOKE SHAFT ASSEMBLY	64227	1	39	SCREEN-fuel inlet	/6424 3	1
18	RING-throttle shaft retaining	64221	1	34	GASKET SET	≠ 67019	1
17	DIAPHRAGM-fuel pump	<i>+</i> 64233	1	35	REPAIR KIT	£07197	1
18	QASKET-fuel pump	67008	1		REPAIR KIT-check valve	65386	1

≠Included in Repair Kit 67197 *Denotes new parts.

art No.	Description	QIY.	Part No.	Des craption	Qty.	Part No.	Downraption	Qfy	Part No.	Description	
2820-5	Collar	1	03718	Valve	2	A-64620-1		1	87286	Clamp	
2628	Pisors	1	03861	Bland	2	64646	Bughing	1	A-67267	Plate	
8136-1	Sleeve	1	69865-6	Bearing	1	04659	Biscottig	1	67340	Proton Rong	
8475	Paint-red	3	63868	Bowd (long)	1	ú46 5 €	Lever	í	67.18G	Button	
3698	Wrench	3	83869	Коре	1	84665-3	Clamp	1	+64089	Reed-nuf,	
87 5 6	Plug	1	69870	Blatang	F	A-64066-8		I	07195	Bearing	
1750	Bleave	1	63875	Rang	1	8 4077	Spering.	í	67409	Boarnog	
-29841-A	Wrene.h	ſ	63677	Btud	2	64ú 86	Borew	1	A-67411	Rad	
3848-2	Anvil	í	63666-1	Roà	1	64669	Berew	۲	*67413-I	Stop	
-23834	Wranch	1	6.9905	Wusher	2	84690	Jat	1	A-67437	Bearing	
-23937-B	Wrench	I	A-63919	Laoo	1	64082	Plog	I	*******	Body mut,	
-33948	Flug	í	A-63920	Filter	1	64683	Soraw	2	*67430	Buille	
-23660	Puller	í	A-63936	Fature	1	4684	Sarew	4	A-67462	Valvo	
972	Bleeve	î	03810	PLute	1	A-64722	Ket-bumper	1	67463	Loud-transf.	
006-2	P]_ta	ī	A-63828	Cover	i	A-64741	Filter	ī	G7484	Loud-toppion	
-24051	Jackstrew	ī	A-03835	Swalah	1	64764	Borsw	1	A-675DI	Сар	
064	Plug	í	A-63889	Lead	ī	A-64797-D		ĩ	*A-67502-A		
		í	A-63842-1		1	64813	Пала	í	67508-2	Btou	
1065	Plug				1			1	*4-07527-1	Cap	
-94067	Plug	I	A-63847	Lano		A-6483B	Arrestor		A-67627	Nut	
078	Bleevs	I	A-03952-A		1	84962	Groning	2		Gasilot	
5107	Paint-blue	3	A-63855-A		1	6 6 904-1	Plate	1	67631		
24138	Reamer	1	Ø 3880	Raos	1	A-81908	Bprooke4	1	497034	Boot	
1173	Driver	1	64021	K .rew	2	64948	Lock	1	A-67081	Carborcior	
1230	Driver	1	84053-1	Bloment	1	90000	Shina	I	A-67699	Fleton & Pin	
1304	Br£	1	64080	Borew	2	85081	Plunger	ĩ	A-67687	Handlo	
1056	Gasket	1	84068	Condensor	1	85092	Nut	I	A-67698	Handle	
008	Clop	1	A-64087	Pointe	I	66129	"O" Rong	I	07200	Valve	
3028	Washer	í	640BB	Block	I	A-06199	Rod	1	*A~67706	Kit-stop	
618	Plug	3	64083	Fell	1	A-65284	Cap	ĩ	*A-87886-A	Muiller	
1734	Downeetor	i	64080	SLIBW	2	60321	Storew	5	*A-68074	Epurk Arrests	ŗ
-33055	Terminal	1	64081	Cool	ĩ	65364	Gaskel	ĩ	OX(58210	Sproakat	
-20022 1428	Cora	1	84102-A	Borew	1	65365	Pin	2	71430	Fin	
		í	84124	Bearing	1	66388	Repair Kit	ĩ	72469	Insert	
423	նիր	2			1	05482	Plug	i	78078	Koy	
411	Barew		64126	Сар			-				
5 8 71	8 Eud	8	64126	Baffle	1	66491	Soceon	1	75120	Ring	
7289-1	Button	I	A-04130	Body	1	00522	Sorew	1	76423	Borew	
8308-1	Beal	I	64133-A	Screw	5	66543-1	Exchanger	1	FASTERIN		
8918-A	Ring	2	84154	Loser1	í	A-6555\$-1		1	80169	9-82 x 7/8	
8388	Gasket	3	64155	Grap	í	85569	Pad	1	60560	8-52 x 1/2	
6328	Сар	í	84132	Washer	1	A-66676-A	Cover	I	80671	6-32 x 3/8	
8405	Boring	1	64221	Rang	I	65686	Plate	1	80572	10-3 <u>2x</u> 0/8	
6408	"O' Ring	9	64224	COVET	1	65582	מנץ	1	80575	8-32 x 1/9	
8408	Rung	1	64226	Throttle	1	A-05808	Vent	1	80605	6-32 \ 5/16	
BS8B-A	Seal	1	64227	Choka	í	A-85666-1		ī	80548	10-32 × 1/2	
8756-2	Sprute	2	84223	Valve	1	65670	Plato	í	80676	$12 - 26 \times 5/8$	
6838-1	Wiener	ī	64229	Valve	ī	65890	Friting	ī	80321	12-21 x 1/2	
8851	Washer	2	64281	Ganket	ī	05768-1	Pig	î	60888	8-36 x 1/2	
	Gronmet	2	64289	Daphragm	ī		Guiket	ī	BOBUI	12-24 x 7/8	
8868						65629			80910	4-40 x 1/4	
1924 -1	Pin	í	64235	Metering	1	65642	foring	3			
8967	Qasket	I	5 £ 236	Spring	2	60389	RIVE	2	809B)	8-32 x 1/2	
8986	Leud	I	84287	Spring	1	66844	SOTOW	I	81065-2	Nut-1/4-28	
a064	Bushing	í	64288	Sprang	I	A-85848	V.dve	1	81098	Not-12-24	
9074	"O" Ring	1	64289	Sprang	1	65949-2	Clamp	1	91112	Nut-5/36-24	
9678-B	Read	4	64240	Sprug	1	65985	Raco inner	1	81126	Nut-6-38	
9904	Scrow	2	64241	Needla	1	A-65986	Drum & Hub	1	83196	Nut-5/16-18	
2876	Gasket	2	64242	Need)e	1	67002	Dover	1	63211	Nut-10-32	
1896-A	Inpert	2	64243	Scroon	ī	87008	Qasket	1	88126	IO-33 x I	
0051	Ba[]	1	04244	Pin	î	07019	Gasket	i	82101	8-02 x 15/16	
9119	Barew	í	64245	Lever	1	A-57028	Housing	÷	82162	8-92 × 1 1/4	
	Cover	1	64352	Seat	1	07066	Grommel	i	B2159	8-52 1 5/8	
9189-2 900-1		1	64263	Retainer	1	A-67079	Line	;	82154	8-32 - 1 7/8	
1204-1	Crankshaft				1	87138-3	Cover	j	82155	8-32 x 2 3/16	
1238-A	Trursr	1	64264	Gasket							
1228	Worm	Í	64867	Gasket	1	69179	Bushing	1	82156	8-d2 x J/1	
3290	ATBUEL	1	A-64293	Filter	1	69185	Washer	1	62178	8-32 x 1	
1361-Á	Caskot	1	64901	Retainer	1	09187	Cover	1	82174	8-32 € 1 1/4	
1544	Lunc	I	64933	Bearing	1	87188	Dupprigni	1	B2177	8-32 \ 6/8	
47-9	Plug	ב	64356	Line	1	A-67189-1		1	82175	8-32 x 1/1	
-69678	Bracket	1	64374	Bushing	1	67191	Stud	4	82179	10-32 x 1 7/8	
3699-2	Cover	3	64993	Scat	1	A-61192-A	Housing	1	B.1009	Washor-1/4	
5498	Washer	j	64405-1	Cylinder	1	67187	Ropin Kit	1	B-1046	W.u.her-F10	
2624-1B	Filto	1	64423	Çщi	î	672.22	Rung	î	8-1056	Witehat - 172	
9637	Rotor	i	64442		2	07265	Gaskot	ĩ	83106	Withhar -#6	
	Plate(mer)	i	64494	Grominal	2		Luniormer	1	61800	Wayher	
3938-B						67275			60300 64016	WILLDOR-M	
9638-A	Pluto(outer)	1	A-61042-44		1	67277	Core	I			
(m) 0.1	Cover	1	64069 - d	Shop	3	67280	Lead	1	B4033	Washer-8/16	
95 71				Padi	1		Candensor	ĩ	64066-1	aur in base - L /T/-	
371J 3714	Shield(aner) Shield(outer)		64610 64614-a	Sorau	2	67251 67251	Module	í I	863D1	Wilshor-5/16 Pin-cotter	

ALWAYS FURNISH MODEL AND SERIAL NUMBER WHEN ORDERING PARTS.



A (UXING) DIVISION PORT OMESTER, N.Y., U.S.A.



PRINTED IN USA 170